

# XIAMETER® RTV-3110, 3112, and 3120 Bases

# General purpose silicone moldmaking rubbers.

# **FEATURES**

- Two-part RTV silicone rubbers
- · Low mixed viscosity
- Adjustable cure times

# **BENEFITS**

- · Easy to use
- Reproduce intricate details
- Works in a wide range of service temperatures

# **COMPOSITION**

 Condensation cure silicone RTV rubbers

#### **APPLICATIONS**

- Recommended for simple patterns with no undercuts.
- XIAMETER® RTV-3110 Base can be used where vacuum de-airing isn't always required.
- Can be used in electronic potting and encapsulating applications.

# **TYPICAL PROPERTIES**

Specification Writers: These values are not intended for use in preparing specifications. Please contact your local XIAMETER® sales representative prior to writing specifications on this product.

Test	XIAMETER <sup>®</sup> RTV-3110 Base <sup>1</sup>	XIAMETER <sup>®</sup> RTV-3112 Base <sup>1</sup>	XIAMETER <sup>®</sup> RTV-3120 Base <sup>1</sup>		
As supplied					
Color	White	White	Red		
Viscosity at 25°C (77°F),					
poise	130	280	280		
Specific Gravity at 25°C					
(77°F)	1.14	1.30	1.45		
Physical and Mechanical Pr	operties, as cu	ured			
Useful Temperature Range,					
°C	-55 to 200	-55 to 250	-55 to 300		
(°F)	(-67 to 392)		(-67 to 572)		
Tensile Strength, die C, psi	395	640	582		
Elongation, percent	170	127	128		
Durometer Hardness, Shore					
A, points	45	58	56		
Electrical Properties, as cured					
Dielectric Constant at 25°C (7	7°F)				
(ASTM D 150)					
100 Hz	3.26	3.56	3.72		
100 kHz	3.16	3.32	3.7		
Dissipation Factor at 25°C (77°F)					
(ASTM D 150)					
100 Hz	.0056	.0135	.0103		
100 kHz	.0022	.0038	.003		
Dielectric Strength, Volts/mil	4=0	1-0			
(ASTM D 149)	456	470	418		
Volume Resistivity, ohm-cm					
(ASTM D 257)	5.68E+14	2.72E+14	3.46E+14		

<sup>1</sup>Results were obtained using XIAMETER RTV-3010-S Catalyst at 10:1 base to catalyst ratio. Wide departures from normal 10:1 ratio may slightly alter physical properties such as hardness and elongation. Based on sample thickness of 125 mm, cured 24 hours at room temperature.

Catalyst	Color	Consistency	Demold Time <sup>1</sup>	Cure Conditions
Dow Corning® 4 (Fast rate, 200;1 ratio, no corrosion inhibitor)	Clear straw	Liquid	10 minutes – 2 ½ hours	Room temperature - any thickness or in confined places
XIAMETER® RTV-3000 F (Fast rate, 20:1 ratio, corrosion inhibitor)	Light tan	Paste	25 minutes – 2 hours	Room temperature – any thickness or in confined spaces
XIAMETER® RTV-3010-S Catalyst (10:1 ratio, corrosion inhibitor)	Light blue	Paste	7-12 hours	Room temperature – any thickness or in confined spaces

<sup>&</sup>lt;sup>1</sup>Demold time varies based on the *Dow Corning* RTV base used with the catalyst.

### **DESCRIPTION**

XIAMETER® RTV-3100 Series are pourable rubber bases that become firm, flexible silicone rubber when cured. There is a choice of three catalysts to select from in order to tailor your working times and cure rates. XIAMETER RTV-3100 Series:

- Is easily mixed and poured
- Cures at room temperature in any thickness
- Gives accurate reproduction of masters for moldmaking
- Provides a wide service temperature range.

#### Catalysts

A common catalyst concentration is 10:1 base to catalyst by weight, which assures more accurate measuring and mixing of catalyst. Varying the catalyst concentration will change the curing rate as indicated on Table I. Decreasing the catalyst level will slow the cure and give longer working and demold times. Keep all catalyst containers tightly closed when not in use.

Note: A 10:1 mixing ratio is not recommended for *Dow Corning* 4 Catalyst or XIAMETER RTV-3000 F Catalyst. Do not use

XIAMETER® RTV-3010-S Catalyst or XIAMETER RTV-3000 F Catalyst when molding polyesters because the polyester can be inhibited. *Dow Corning* 4 Catalyst is recommended for polyester molds.

# **HOW TO USE**

# **Substrate Penetration**

The surface of the original should be clean and free of loose material. If necessary, and in particular with porous substrates, use a suitable release agent such as petroleum jelly or soap solution.

### Mixing

Thoroughly stir XIAMETER RTV-3100 Series bases before using, as filler separation may occur upon prolonged standing. Weigh the base and appropriate catalyst into a clean container, mix together until the catalyst is completely dispersed in the base. Hand or mechanical mixing can be used, but do not mix for an extended period of time or allow the temperature to exceed 35°C (95°F).

With the exception of XIAMETER RTV-3110 Base, it is strongly recommended that entrapped air be removed in a vacuum chamber, allowing the mix to completely expand and then collapse. A vacuum of at

least 28 inches of mercury should be held until most bubbling has ceased. After an additional 1-2 minutes under vacuum, the mix should be inspected and if free of air bubbles, can then be used. A volume increase of 3-5 times will occur on vacuum de-airing the mixtures, so a suitably large container should be chosen.

Caution: Prolonged vacuum will remove volatile components from the mix and may result in poor thick section and non-typical properties.

Air entrapment can be minimized by mixing a small quantity of base and catalyst, then using a brush, painting the original with a thin layer. Leave at room temperature until the surface is bubble free and the layer has begun to cure. Mix a further quantity of base and catalyst and proceed as follows to produce a final mold.

# Pouring the mixture and curing

Pour the mixed base and catalyst as soon as possible onto the original, avoiding air entrapment. The catalyzed material will cure to a flexible rubber and the mold can then be removed (see table of typical properties for details). If the working temperature is significantly lower than 23°C

Table I: Base/Catalyst Ratios, Working Times and Demold Times

	Base/Catalyst Mixing Ratio by Weight	Approximate Working Time	Approximate Demold Time
XIAMETER RTV-3110 Base			
XIAMETER RTV-3010-S Catalyst	5:1	1 hour	5 hours
•	10:1	2 hours	7 hours
	20:1	3 hours	12 hours
XIAMETER RTV-3000 F Catalyst	10:1	10 minutes	27 minutes
•	20:1	40 minutes	80 minutes
Dow Corning 4 Catalyst	100:1	3 minutes	10 minutes
,	200:1	5 minutes	20 minutes
	400:1	20 minutes	2 hours
XIAMETER RTV-3112 Base			
XIAMETER RTV-3010-S Catalyst	5:1	30 minutes	6 hours
•	10:1	1 hour	8 hours
	20:1	2 hours	12 hours
XIAMETER RTV-3000 F Catalyst	10:1	12 minutes	37 minutes
•	20:1	28 minutes	100 minutes
Dow Corning 4 Catalyst	100:1	2 minutes	10 minutes
,	200:1	5 minutes	20 minutes
	400:1	15 minutes	1½ hours
XIAMETER RTV-3120 Base			
XIAMETER RTV-3010-S Catalyst	5:1	30 minutes	6 hours
•	10:1	1 hour	8 hours
	20:1	2 hours	12 hours
XIAMETER RTV-3000 F Catalyst	10:1	8 minutes	25 minutes
, ,	20:1	25 minutes	1½ hours
Dow Corning 4 Catalyst	100:1	2 minutes	10 minutes
,	200:1	5 minutes	30 minutes
	400:1	15 minutes	2½ hours

(73.4°F), the cure time will be longer. If the room temperature or humidity is very high, the working time of the catalyzed mixture will be reduced. The final mechanical properties will be reached within 7 days.

# **Deep-Section Cure**

XIAMETER RTV-3100 Series may depolymerize when overheated in total confinement. To minimize this effect, electrical pottings which must operate in total confinement at elevated temperatures must be given a graduated post cure which allows volatiles to escape. During the graduated post cure, the temperature should be increased approximately 25°C (77°F) per hour depending upon thickness of the potted

section. A final bake of two to four hours at a temperature 50°C (122°F) degrees above the maximum operating temperature of the device is recommended.

# **Use at High Temperatures**

Some molds produced from condensation cure silicone rubbers can degrade when exposed to temperatures above 150°C (302°F) over a period of time or when totally confined in storage at high ambient temperatures. This can result in softening and loss of elastic properties.

# **Electronic applications**

XIAMETER RTV-3100 Series can be used in electronic applications using the RTV-3010-S or RTV-3000 F

catalysts. The cured rubbers exhibit good dielectric properties.

In potting with XIAMETER RTV-3100 Series, the part or assembly to be packaged is placed in a form with clearance at all points when sealing is necessary. This form may be made of paper, aluminum foil, metal or plastic.

A release agent may be used to aid in demolding.

When printed circuit boards and similar assemblies are to be dip coated, select the viscosity grade that will give the desired coating thickness.

To apply XIAMETER RTV-3100 Series as a conformal coating, immerse parts in the catalyzed compound, withdraw them slowly, pausing just before the part leaves the dip tank to minimize stringing and hang on a rack to cure. Allow one to two hours between dips. Two dips in a low viscosity grade encapsulant are suggested for optimum protection.

For maximum assurance of void-free potting, pour the silicone RTV rubber, then apply a vacuum to facilitate the removal of air.

# PRODUCT SAFETY INFORMATION

PRODUCT SAFETY INFORMATION REQUIRED FOR SAFE USE IS NOT **INCLUDED IN THIS** DOCUMENT. BEFORE HANDLING, READ PRODUCT AND MATERIAL SAFETY DATA SHEETS AND CONTAINER LABELS FOR SAFE USE, PHYSICAL, **ENVIRONMENTAL, AND HEALTH HAZARD** INFORMATION. THE MATERIAL SAFETY DATA SHEET IS AVAILABLE ON THE XIAMETER® WEB SITE AT WWW.XIAMETER.COM.

### **STORAGE**

Product should be stored at or below 32°C (89.6°F) in original, unopened containers. The most up-to-date shelf life information can be found on the XIAMETER Web site in the Product Detail page under Sales Specification.

# **LIMITATIONS**

This product is neither tested nor represented as suitable for medical or pharmaceutical uses. Not intended for human injection. Not intended for food use.

# LIMITED WARRANTY INFORMATION – PLEASE READ CAREFULLY

The information contained herein is offered in good faith and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information should not be used in substitution for customer's tests to ensure that our products are safe, effective, and fully satisfactory for the intended end use. Suggestions of use shall not be taken as inducements to infringe any patent.

Dow Corning's sole warranty is that our products will meet the sales specifications in effect at the time of shipment.

Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted.

DOW CORNING SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY.

DOW CORNING DISCLAIMS LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.